



## Front swaybar swap

only fits L20B, CA20 - Does not fit SR20

### Parts needed

- AUS R31 front swaybar (Skyline or Pintara)
- AUS R31 D shackle & link pin bushes (Better option is to use new nolathane bushes)

OR

- AUS S12 front swaybar
- AUS S12 D shackle & link pin bushes (Better option is to use new nolathane bushes)

### How to

- jack up car and put on chassis stands
- remove front wheels
- undo swaybar link pin bolts (12mm?)
- pull the top rubber off
- undo swaybar D shackles(14mm?)
- pull out 910 swaybar
- tap old pins out of lower control arms with a mallet (only if replacing with new bushes)
- sometimes the pin wont come out easy because the tubular metal spacer has rusted on, worst case senario will be having to pull the control arms out and the spacer gripped in a vice
- insert new nolathane bushes and replace pins
- drop new R31 swaybar onto pins and replace bushes and top nut
- using R31 D shackle bushes, bolt the D shackles back onto the chassis